

**Celadon Inc.**  
**RCV-5000 IR to RS-232 Output Table**  
**Device: RUNCO VX101c Projector**

Infrared Remote Control: Philips PRONTO, Niles Intellicontrol  
 Infrared Code Format: NEC - Device ID: 7B02  
 Infrared Pronto Data File(s): See "IR Code Read Me - RCV-5000.txt" for complete description  
 Infrared Receiver: Celadon RCV-5000 Infrared to RS-232 Receiver  
 RCV-5000 Data File: runco2\_r.hex  
 Data: 9600 Baud, 8, N, 1, ASCII Output  
 Standard Pinout  
 Command Format: <input><aspect ratio>  
 Dash (-) is used in place of input or aspect ratio for single commands  
 Carriage Return at end of each command

Runco VX101c Command	Pronto Button	RCV-5000 Output
Power - ON	0	ON
Power - OFF	1	OF
Input - Composite	2	0-
Input - S-Video	3	1-
Input - Component	4	2-
Input - Pass Through	5	3-
Aspect - Anamorphic	6	-A
Aspect - LetterBox	7	-L
Aspect - Standard 4:3	8	-S
Aspect - HDTV (for pass through)	9	-H
Aspect - Computer (for pass through)	10	-C

Celadon, Inc.  
 50 Mitchell Blvd.  
 San Rafael, CA 94903  
 Sales: (707) 648-1098  
 Main Tel: (415) 472-1177  
 Main Fax: (415) 472-1179  
 sales@celadon.com